

## **Instructional Station How-To**

1. To start up Projector press **Power** on the **Projector Remote** connected to the desk.
2. Select the appropriate Source by pressing either **Computer** or **Video**.

### **For the Video or Elmo Document Camera**

1. Press the **Video** button on the Projector Remote, until you select **Composite Video**.
2. Press **Power** on either the VCR or the Elmo Document Camera.
3. On the **Black Video Switcher** on the left of the Elmo Press **Ch. 1 for VCR. Ch.2 for the Elmo**.

### **For the Computer:**

1. Press the **Computer** button on the Projector Remote.
2. Power on the Computer and enter in the appropriate Login Information as **posted on the computer monitor**.

### **To Shut Down the System:**

Simply press **Power** on the Projector Remote.