

Video Selector How-To

1. Start up the Projector by pressing **Power** on the **Projector Remote** connected to the desk.
2. Select Video Source 2 pressing either **Computer** or **Video**.
3. Press **Power** on the VCR or Laser Disk Player.
4. Press **Power** on the Audio Selector and then press the **DVD/Ch 5.1** button.
5. On the **Gray Switch Box**, select **Ch.1** for the VCR **OR Ch.2** for the Laserdisc Player.

To Shut Down the System:

1. Press **Power** on the **Projector Remote** twice.
2. **Eject** your video cassette or laserdisc.
3. Press **Power** on the VCR/Laserdisc Player.
4. Press **Power** on the Audio Selector